

NEDSP1061-KBD Installation tips to avoid damaging your radio

1. When removing the smd cap on the FT-817 pcb, do it with caution.
2. Remember TOUCH AND GO! Let it cool down! Why? The pads will come off board easily if you don't!
3. If you don't have the right tools DON'T TRY THIS!!!
4. It's easy to build up the pad with a tip full of solder. Touch and go! Then let cool. Let cool after each step! Then you can do a touch and go install of wire.
5. Then use some masking tape to secure wires to insure you don't tear the pads off after a good install. Pads will tear off very easy. It's also a good idea to tape the wires on the top side of the board
6. Be sure before you reassemble the bottom of board that it is nice and clean of stray solder.